Lime-A-Way Extra – DISHWASHER DESCALING

HS/TC/024/03 – August 2017



READ BEFORE STARTING



Wear PPE where advised in each step

GLOVES & GOGGLES & APRON

You MUST refer to the CPAs & Task Cards for your PPE Requirements



Disable detergent by safely removing feed tube from bottle







Ensure dishwasher has been drained and refilled with clean water



Dispense 3 pushes 30ml (pelican pump) per 10L of water into wash tank



Run dishwasher for 3-4 cycles



Inspect dishwasher and repeat if necessary



6

Drain and rinse dishwasher before refilling for use



7

6

Place feed tube back into detergent bottle











