

NESPRESSO DESCALING AGENT- NDA 14

Descaling of Nespresso Machine HS/TC/098/02 - March 2019

Please Note: The instructions below refer to the use of NDA 14 only and could vary depending on the model of the Nespresso Coffee Machine. Please ensure to refer to a relevant user manual for full details on descaling your Nespresso machine.



READ BEFORE STARTING



Wear PPE where advised in each step

GLOVES AND GOOGLES

You MUST refer to the CPAs & Task Cards for your PPE Requirements



1

Switch the machine off.



2

Fill the water container with 1 litre of water + 2 packs of NDA14.




3

Place the container in the back of the machine and place an empty 1.5l container under the dispense nozzle



4

Press and hold the Ristretto button while turning the machine on.



5

Once the descaling process has finished. Remove the waste receptacle and pour the liquid down the sink.



6

Wash and rinse the water container. Refill with 2 litres of fresh water and place back on the machine.



7

Press and hold the button on the right to start the automatic rinse process, repeat this twice.



If in any doubt about the PPE required, please refer to the separate COSHH Product Assessment or your HSE Manager