

THERMOBLUE (FORMER THERMOCLEAN) & THERMORED – Milk system cleaner



HS/TC/095/02 – February 2019

READ BEFORE STARTING



Wear PPE where advised in each step


GLOVES & TIGHTLY SEALED GOGGLES

The hazard pictogram on the product container may be different to that on this CPA & Task Cards. You MUST refer to the CPAs & Task Cards for your PPE Requirements





1 Clean machine according to manufacturer's instructions using any of the following chemicals. Always follow instructions on the touch screen of the machine.



2 Remove the milk container of the fridge and clean it.





3 Pour 60 ml of ThermoBlue/ThermoRed into the container and put it back into the fridge.





4 Replace the suction tubes back into the container and press the cleaning key on the display. The machine begins with the automatic cleaning which rinse for 12 cycles.




5 After the 8th cleaning cycle (after about 10 min.) the machine demands to empty and clean thoroughly the milk container.





6 Clean the milk container, the suction tube and hull thoroughly with water and put the container back to the fridge.



7 After pressing the cleaning key, the remaining 4 cycles will be started. This takes about 5 min.



8 After the 12th cleaning cycle, clean the milk container and suction tube thoroughly.



If in any doubt about the PPE required, please refer to the separate COSHH Product Assessment or your HSE Manager