CLEARING BODY SPILLS – Desguard 20

READ BEFORE STARTING PROCEDURE



Please reference the relevant Safety Data Sheets, risk assessment and safe system at work documents.



WS.TC.038.01

Always wear correct PPE







2

For hard flat surfaces, spray Desguard 20 directly onto spill



(3)

Allow contact time and then use a scoop to pick up material



Dispose of collected material in bio-hazard bag



For uneven surfaces, use paper towels to remove as much fluid as possible



Apply 3% dilution of Desguard 20 to the affected area and allow 60 minutes contact time



Use paper towels to wipe area and dispose of collected material in bio-hazard bag



5540 ECELAB®

Helpline: 02920 855540